



2 Pack Mineral Based **PLASTER PLUS** THIN FILM CEMENT RENDER COATING SYSTEM

DESCRIPTION	Similar to a sponge finished (scrub fine) render in appearance, PLASTER PLUS is a 2 pack polymer modified mineral blended plaster. Because of its adhesion, PLASTER PLUS is free hand applied over Quickwall keyed SKIMCOAT to a smooth undulating sanded finish and top coated with Quickwall Aqua Seal membrane paint or alternatively any premium grade exterior paint.
SUITABLE FOR	<ul style="list-style-type: none">• Bricks• Prepared Concrete• Single Skin Masonry Blocks• Quick Clad• Quick Panel• Hebel Products
SPECIAL FEATURES	<ul style="list-style-type: none">• Faster than solid plaster to apply, covering more surface area daily for the same number of applicators.• Incorporated waterproofing additives.• Excellent for packing thick sections in one application, maintains internal moisture for thin set plaster while curing, even suction providing extended control of finishing techniques.• Highly modified cement. Environment friendly, wash up in water.
Even Substrates	Splash coat the substrate with Quickwall SKIMCOAT prior to the PLASTER PLUS application.
Uneven Substrates	Apply 3 mm minimum thickness of Quickwall SKIMCOAT to the substrate, leaving a keyed rough flat base coat, prior to PLASTER PLUS .
Non-Flexible	PLASTER PLUS is the least flexible coating with similar behaviour to solid plaster.
PAINTING	The substrate can be painted after 48 hours under normal conditions.
NOTE	PLASTER PLUS can be applied by plaster / mortar machines without blockages commonly experienced with standard cement plaster.
APPROVED FOR	Government Projects, Defence Housing Authority, Commercial and Domestic applications.
GUARANTEE	Ten years when applied by an Approved Applicator and in accordance to Quickwall specification.

SPECIFICATION

- 1st Coat: Apply Quickwall SKIMCOAT
- 2nd Coat: Apply Quickwall **PLASTER PLUS**
- 3rd Coat: Apply 1 coat of AQUASEAL
- 4th Coat: Apply 1 coat of AQUASEAL

Notes: For best results Mid range yellows and reds apply 3 coats of Aquaseal.

Notes: For hi-rise buildings with difficult logistics apply 3 coats of Aquaseal.

Website
www.quickwall.com
www.quickwall.com.au