



2 Pack Mineral Based **SPRAY TILE** SPRAYABLE FLUID TILES OR SEAMLESS FLOORS

DESCRIPTION

SPRAY TILE is a 2-pack polymer ceramic cementitious material for seamless or patterned floors.

Patterns are generally created by adhering to the floor cross woven filament tape in the desired format, logo, decal etc. **SPRAY TILE** is then spray-applied by gravity feed hand held hopper gun or in the case of exceptionally large surface areas applied by rotor screw machines.

SPRAY TILE will give minor colour variations to the floor's finish and therefore it is recommended that the complete surface area be coated in a continuous manner.

Secondary colour spotting with another hopper gun provides an attractive finish but is used very sparingly.

SPRAY TILE is tough, is finely textured and withstands heavy traffic.

SUITABLE FOR

Patios, driveways, new concrete or dress up old unexciting concrete causeways.

SEALER

SPRAY TILE must be sealed with either:

QUICK SEAL (solvent base) – minimum 2 coats, OR

CLEAR SEAL (acrylic base) – 3 coats if in high traffic areas.

SPECIFICATION

1st Coat: Apply Quickwall SKIMCOAT

2nd Coat: Apply Quickwall PRIMER

3rd Coat: Apply 1 coat of **SPRAY TILE**

4th Coat: Apply 1 coat of QUICKSEAL

5th Coat: Apply 1 coat of QUICKSEAL

Notes: Clear Seal may be used instead of Quick Seal.

Website

www.quickwall.com
www.quickwall.com.au



How to apply **SPRAY TILE** IN 5 EASY STEPS

STEP 1. PREPARE SURFACE

Acid etch concrete with Hydrochloric Acid
Dilute Acid 5:1 for average concrete.
Use a plastic watering can to spread acid.
Use a stronger solution if your concrete is polished or very dirty.
Treat oil stains with appropriate degreaser.
Pressure wash etched area with a high pressure water blaster – recommend 2000 to 3000 PSI, let dry.

STEP 2. PRIME

Prime washed slab with Q.W. Polymer 6:1 (6 parts water to 1 part polymer)
Use roller.

STEP 3. APPLY SKIMCOAT

FOR COLOURED GROUT LINES
Using SKIMCOAT grey for dark colours or SKIMCOAT white for light colours.
Mix with pre-coloured polymer ratio 3:1 (3 parts water to 1 part polymer).
Trowel over prepared surface.

TAPING GROUT LINES
Using 6 mm or 12 mm filament tape, tape floor to the required tile size.

STEP 4. SPRAYING TILES

Using pre-coloured Polymer diluted 3:1 (3 water to 1 Polymer).
Mix SPRAY TILE 25kg bag with a pre measured quantity of Polymer – approx. 6-7 ltrs,
more for a fine finish inside and less for a coarse finish outside on driveways and inclines.

STEP 5. TO FINISH

When dry, remove tapes, use air blower to clean.
Apply 2 coats of QUICK SEAL

Spray Tile comes in 30 eye catching colours.

Customer Service about this product

Ph: 07 3216 5544
Fx: 07 3216 5533

e-mail: info@quickwall.com.au
or contact your nearest Distributor

SPECIFICATION

1st Coat: Apply Quickwall SKIMCOAT

2nd Coat: Apply Quickwall PRIMER

3rd Coat: Apply 1 coat of **SPRAY TILE**

4th Coat: Apply 1 coat of QUICKSEAL

5th Coat: Apply 1 coat of QUICKSEAL

Note: Clear Seal may be used instead of Quick Seal.